

Bead Breaker Hand Grip Install QRG

Why:

As a company, we have experienced an increase in hand injuries due to hands slipping off of bead breaker handles. In an effort to reduce hand injuries, we need you to install hand grips on **ALL** tire changer bead breaker handles.

This will help to:

- Lower the chance of your hand slipping while breaking a bead
- Provide a backstop if your hand does slip

What you will need:

- Quick Dry Patch Cement W/ Brush (DT-7362)
- Hand Grip
- Tire Changer Bead Breaker Handle



- Remove the brush from the can
- Remove the excess cement on the inside opening of the open patch cement can
- Coat the first ½" to 1" of the opening of the grip
- **Be sure to wear latex gloves when applying cement**



- Slide the open end with the applied cement over the handle
- Slightly twist as you push the grip over the entire length of the handle

It is recommended that this process be done at the end of day to ensure the cement dries

