

Corvette Jack Adapter QRG

Purpose To be able to properly and safely lift Chevrolet Corvettes.

Using the Corvette Jack Adapter Follow these steps when lifting Chevrolet Corvettes:

Step	Action
1	Reference the CSL to verify the vehicle will need a jack adapter.
2	Stage the adapter storage container prior to pulling the vehicle and verify correct adapters have been pulled. 
3	Only use flat bays and jacks to service the vehicle.
4	Take the adapters from the container and place keys into one of the container halves. Note: This will help later with the final removal of the adapters during Steps 9 and 10. 

Using the Corvette Jack Adapter

Step	Action
5	Locate the first proper lift point on the undercarriage of the vehicle.
6	Place the adapter in the lift point and turn it 90 degrees to lock in place
7	Center jack with the adapter and begin to raise vehicle.

Using the Tesla Lift Adapter

Step	Action
8	<p>Repeat Steps 5 through 7 for the remaining lift points.</p>
9	<p>Once the service has been completed, lower the vehicle and remove the adapters and jacks.</p>
10	<p>Important: Place the adapters back into the storage container; then return the container to its proper location in the store.</p>