

## Pulling Vehicles Into the Bay



**CRITICAL TO  
SAFETY**

### ***A valid driver's license is necessary to move vehicles.***

- Come to a complete stop to ensure there are no employees in front or behind the vehicle. This includes employees changing, balancing, or using the inflation cage.
- Honk twice
- Make sure there is enough clearance for vehicles that are lowered or have ground effects.
- Make sure the guide is standing to the side as the vehicle enters the bay.
- Stay focused on the person guiding and their hand signals to ensure the vehicle is squarely loaded on the lift.
- Keep driver's door closed as vehicle is being pulled onto the lift.
- Employees can return to work when the vehicle has placed in park and shut off.



**CRITICAL TO  
QUALITY**

- Use low profile jacks for these vehicles.
- Check before entering bay that area is clear of debris or tools.

### **The Whys**

- Checking the vehicle for existing damage allows us to document it before servicing the vehicle
- Certain ground effects can be damaged while pulling onto a lift
- Guiding vehicles into the bays ensures there are no obstructions in the path of the vehicle
- Do not leave the driver's door open because doors have been damaged striking walls, tool stands, and pillars
- Opening vehicle doors while pulling into the bay increases the risk of damaging the customer's vehicle
- Employees must stand to the side when guiding in case of driver error or unintended acceleration