

DTMI – Inflating Assemblies

Note: Follow all existing Best Practices unless a change in process is identified in this document which takes precedence.

Inflating Assemblies

- Seal the assembly on the changer
- Note: Tire changer may not have a PSI limiter on it
 - Never inflate over 15 PSI on the changer
- Place the inflation cage on the ground at the rear of the van
- Transfer the tire/wheel assembly to the inflation cage and set the proper PSI on the auto inflator
- Attach the hose to the valve and stand clear of the area

Whys

- The inflation cage will protect technicians and pedestrians from tire ruptures
