

TECHNICAL GROUP BULLETIN

AUDI A8 AIR SUSPENSION LIFTING INSTRUCTIONS

1. Start car.
2. Information screen will pop up.
3. Select the "CAR" button on center console



4. Then press the "SETUP" button on the center console
5. The screen should offer you two choices, Trailer towing, Vehicle Jack mode.



6. Rotate the dial on the center console until Vehicle Jack mode is highlighted.
7. Press down on the dial to select
8. Rotate the dial to toggle between "ON" and "OFF"
9. Turn to the "ON" position and press down on the dial to select.
10. Repeat steps after service to turn OFF the Vehicle Jack Mode.