

DTMI – Balancing Using the SWP00

Note: Follow all existing Best Practices unless a change in process is identified in this document which takes precedence.

Process

- Select 'Set Weight Mode' on the main screen
- Select 'Tape-Tape' or 'Clip-Clip' mode depending on the type of wheel weight
- Rotate the laser dial to point in the middle of where the inner weight is to be placed, press the foot pedal to record the position
- Rotate the laser dial to point in the middle of where the outer weight is to be placed, press the foot pedal to record the position
- Press start to perform the spin
- The wheel will servo to the inner weight position, rotate the laser dial back to your inner weight position. The laser will blink when centered on the correct weight position.
- Apply wheel weights

Whys

- Choosing the proper weight mode for the wheels allows for the best overall balance.